


ARCTIC SILVER QUIET DRIVE CROSS TRAINER 95X-0XXX-03




Customer Support Services
PARTS MANUAL
Rev 31 Jul 2008

OPERATION MANUAL	M051-00K62-A107
SERVICE MANUAL	M051-00K62-A149
TOUCH UP PAINT: SPRAY CAN	0017-00008-0204
.5 OZ BOTTLE W/APPLICATOR .33 OZ PEN	0017-00008-0205 0017-00008-0206
HARDWARE BAG	AK62-00152-0001
PLUG IN OPTION 120/60	GK62-00002-0018
PLUG IN OPTION 240/50 UK	GK62-00002-0019
PLUG IN OPTION 240v AUS	GK62-00002-0020
PLUG IN OPTION 230/50 CONT	GK62-00002-0021


UNLABELED PARTS	
DESCRIPTION	PART NO.
PLATE: DRIVEFRAME; CLAMP B	0K62-01104-0000
KIT: SERV; PLUG-IN; 230/50 CON BM	GK62-00002-0021
CARD: WARRANTY COMMERCIAL +	MO51-00K62-A107

	Page
CONSOLE SUPPORT & DEADSHAFT COVERS	4
HANDLEBARS AND BULLHORNS	5
CONSOLE AND RELATED COMPONENTS	6
UPPER FRAME HARDWARE	8
ROCKER ARMS AND PEDAL LEVERS	8
CRANK COVER AND LOWER CAPS	10
LOWER FRAME SHROUDS AND HARDWARE	11
PEDAL LEVER COMPONENTS	12
PCB, BATTERY, REED SWITCH & BRACKET	13
BEARING-INSERT ASSEMBLY	14
CRANK ARM PULLEY ASSEMBLY	15
DRIVE MODULE	16
DRIVE MODULE HARDWARE	17
CABLES	18

Note: The 95Xi comes with both Telemetry and LifePulse sensors.




Handlebars and Bullhorns



*Right Bullhorn Assembly consists of: AK62-00057-0001 Bullhorn, 0K62-01136-0000 Grip and 0K62-01199-0000 Gasket Left Bullhorn Assembly consists of: AK62-00058-0001 Bullhorn, 0K62-01136-0000 Grip and 0K62-01199-0000 Gasket

Console & Related components




CONSOLE	OVERLAY/BEZEL/SWITCH	LANGUAGE
AK62-00329-0001	AK62-00191-0001	Eng + Met
AK62-00329-0003	AK62-00191-0003	Ger/Met
AK62-00329-0004	AK62-00191-0004	Spn/Met
AK62-00329-0006	AK62-00191-0006	Jap/Met
AK62-00329-0007	AK62-00191-0007	Frn/Met
AK62-00329-0008	AK62-00191-0008	Ital/Met
AK62-00329-0009	AK62-00191-0009	Dut/Met
AK62-00329-0010	AK62-00191-0010	Port/Met
AK62-00329-0014	AK62-00191-0014	Turk/Met

ARCTIC SILVER QUIET DRIVE 95Xi

Upper Frame Hardware

95X-0XXX-03 S/N AXB100000 and up




140,000	NI~+	Shown	
Hems	$\mathbf{I}\mathbf{X}(t)$	\sim nown	١-


Accessory Tray	0K62-01022-0000
Mounting Screws (2)	0017-00101-1846

Rocker Arms Kit GK62-00002-0070 contents:


> Rocker Arms (2) Hardened Spacers (2) Oilite Washers (2) Retaining Rings (2) *Loctite 620* Alcohol pad

Rocker Arms AK62-00002-0070 Shaft Collar w/Screws 0K61-01259-0000







Lower Frame Shrouds & Hardware



Pedal Lever Assembly Components






Bearing-Insert Assembly – AK62-00299-0000

Service Kit- GK62-00002-0044 Includes:


- 1- crankshaft
- 2- bearings
- 2- sets of bearing flanges
- 4- nuts and washers

Service Kit- GK62-00002-0045 Includes:


- 1 intermediate shaft
- 2 bearings
- 2- sets of bearing flanges
- 4- nuts and washers



Crank Arm Pulley Assembly



Drive Module



Drive Module Hardware

